




Search2

Multi-function Motile Headlamp






















rediffical ratameters							
	Press and holdthe button for 1s	Modes	Lumen	Burn time	Lighting distance	Power source	Weight
	Distance light	Midd l e	75	<u></u> 20	70m	4*AA	165g (without battery)
		High	230	<u></u> 6	150m		
	Flood light	High	68	<u></u> 13	10m		
		Low	3	<u></u> 200	3m		
		Strobe		-			
	Red	High		<u></u> 180			
		Strobe		_			
		SOS		_			

Pictures used on the package only for reference. Parameters might be influenced by different environment






Constant lighting battery case

Red

SUREI:

200 150 Distance High 100 50 12 20 24 28



English

Product:

- ★ A multi-function motile headlamp with one ultra bright LED & two white LEDs & two red LEDs
- ★A super-bright high power LED branded Cree provides focus lighting
- ★ Two side white LEDs provide floodlight
- ★Two side red LEDs provide red constant, strobe, and SOS signals
- ★Three kinds of lighting brightness; high, medium and low brightness.

Instructions for use:

- ★The mode change between the white LED and red LEDs please refer to Chart2
- ★ Do not use this product in the extremely cold or hot environments (below -30 °C or above 60 °C).
- ★ This product is ordinary waterproof IPX6. Do not use it under the water, or the circuit fault may be caused by water seepage.

- ★Use high-quality alkaline batteries or Ni-MH rechargeable batteries for products.
- ★Do not use rechargeable lithium batteries, so as not to exceed the rated voltage.
- ★Do not use batteries of different brands or mixed old and new batteries.
- ★ The battery life is affected by different brands, different ambient temperature and different lighting modes.
- ★Please recycle used batteries reasonably.

Maintenance:

- ★If the product is affected with damp, remove the battery
- ★Do not make the lamp lenses rubbing with other hard objects as the worn lens will affect the light.
- ★If you are not using the lamp within a month, remove the battery to prevent battery depletion or battery fluid leakage.

Troubleshooting:

- ★If the battery is installed but the lamp does not work properly, please:
- -Press the switch button several times to try.
- -Check if the battery is correctly installed.
- -Check whether there is debris on the contacts, which lead to poor contact.
- -Check if there is water inside the lamp. After it is dried. try the button again.

Caution:

- ★Before the lamp is used, be sure to read this manual carefully for proper use and maintenance.
- ★ Children under 12 years should use the product under the adult's supervision and guidance.
- ★ Always set aside a spare lamp and a few spare batteries.
- ★ Do not disassemble this product.
- ★ Do not attempt to modify the product.

★The Company promises to each customer solemnly, for quality problems caused by the product design or manufacturing defect, you can contact your local dealer for warranty issues against the invoice and the proof of purchase within two years from the date when it is purchased, but the damage caused by improper use does not belong to this range.

★擁有一顆高亮白光LED燈珠與兩顆白光LED加紅光LED的 多功能運動頭燈

中文

- --1顆超高亮美國科瑞大功率燈珠,提供聚光照明
- --2顆側邊白光燈珠,提供泛光照明
- --2顆側邊紅光燈珠,提供紅光照明與信號照明
- ★三檔照明亮度: 高亮、中亮、低亮

使用說明:

- ★白光與紅光工作模式的切換請參考圖表2
- ★請勿將本品在零下30 C以下或零上60 C以上的極寒極熱環
- ★本品僅限普通防水IPX6、請勿潛水使用、否則將有可能因 滲水而造成燈具的電路故障

- ★請使用優質鹼性電池或鎳氫充電電池爲本品供電
- ★請勿使用充電锂電池,以免紹出額定電壓
- ★請勿將不同品牌電池或新舊電池混合使用
- ★電池使用壽命受不同品牌、不同環境溫度以及不同照明模
- ★請合理地回收廢舊電池

- ★産品受潮後、請將電池卸下並晾幹
- ★請勿將燈罩前鏡片與其它硬物摩擦,若鏡片磨損會影響
- ★若未来一个月内不使用头灯、請將電池取出、以免電量耗 損或電池漏液

常見故障:

- ★如果安装電池後燈具無法正常工作,請:
- --多試幾次開闢按鍵
- --檢查電池極性安裝是否正確
- --檢查觸片是否有雜物而導致接觸不良
- --檢查燈具是否有進水現象,可晾幹後再試

敬告:

- ★在開燈使用前,請務必認真閱讀本說明書,以便正確地使用 與保養
- ★12歲以下孩童請在大人監管與指導下使用本品
- ★永遠預留一個備用燈具以及幾組備用電池
- ★請勿自行拆卸本品
- ★請勿自行改裝本品

質保:

★本公司向每位顧客鄭重承諾,因產品設計或制造存在缺陷而 造成的質量問題、可在購買之日起兩年內憑發票和購買憑證 與當地經銷商聯絡保修事宜、但因使用不當造成的損壞不屬 于此範圍



Интернет-магазин светодиодных фонарей

www.sunreegear.com