



MOON RC2 Manual

How to change the modes?

1. Low → High → Middle → Moonlight → Off (One press to switch).
2. Strobe → Off (Long press 1.5s to start Strobe mode).

How to turn off MOON quickly?

You can press the button over 1.5s to start Strobe mode, then just one more press to turn off.

NOTICE

1. Keep MOON away from water and excessive dust.
2. Children should use MOON accompanied by an adult.
3. Do not disassemble MOON or operate the MOON if it is damaged in any way.
4. The MOON has short circuit protection. Note that MOON does not prevent batteries from internal short-circuiting.

WEBSITE & ANTI-FAKE INQUIRY

1. Welcome to visit our company website to get more information www.xtar.cc and contact us by e-mail: info@xtar.cc
2. Follow us on Facebook:
[www.facebook.com/Shenzhen XTAR](http://www.facebook.com/ShenzhenXTAR)
3. Anti-fake inquiry: A group of eighteen-digit number could be gained by scraping the anti-counterfeiting label on our WARRANTY CARD. Then, input it to the corresponding query window in our service column of our official website to distinguish the product's authenticity.
4. Thank you for choosing our excellent products, your satisfaction and feedbacks are essential to our progress.