

Usage and Maintenance

- ⊙ Please don't disassemble the sealed head, doing so can cause damage to the flashlight.
- ⊙ High-performance flashlights require batteries capable of high current discharge. We strongly recommend the use of rechargeable batteries for cost-effective high performance lighting.
- ⊙ Please take your battery out of the flashlight if you are not planning to use it for prolonged periods, to avoid depletion and leaking of the battery content, potentially resulting in damage to the flashlight.
- ⊙ Please replace the O-ring if it becomes damaged after prolonged use. Lubricate the O-rings regularly in order to avoid erosion of the rubber. Doing so will also maintain the flashlight properly sealed from water;
- ⊙ Clean the contacts of your light periodically, especially when the flashlight flickers abnormally or does not seem to light up.
- ⊙ If the light does not seem to work properly, one of the following may be the cause:
Cause 1: The batteries are depleted or damaged and need to be replaced.
Solution: Replace the batteries (confirm the correct installation of the positive and negative poles).
Cause 2: The threads, PCB board contacts, or other contacts are contaminated.
Solution: clean the contact points with an alcohol-soaked cotton swab.
 If the above methods do not solve the issue, refer to the warranty policy and contact your distributor.

5

Product Warranty

Acebeam guarantees flashlight against defects in material and workmanship. Flashlight products that are found to be defective under normal use within 24 months of the period of purchase date will be repaired or replaced without charge. This warranty does not cover damage caused by accident, unreasonable use or product alteration. Failure to follow the general maintenance directions could result in damage to your flashlight that may not be covered by Acebeam warranty.

If this flashlight should prove defective, the product will be repaired or replaced under the above terms. Please contact Acebeam or your original Acebeam dealer for warranty return instructions.

Warning


T10 is a high intensity lighting device and capable causing eye damage, avoid shining the light directly into the eyes.

SHENZHEN MICROBLUEBEAR TECHNOLOGY CO., LTD

Tel: +86-0755-28101361
<http://www.acebeam.com>
 E-mail: admin@acebeam.com
 Address: Longhua Industrial Park No. 3 Baoan District, Shenzhen City, Guangdong, China

6

ACEBEAM™
 An Excellent Manufacturer



Acebeam T10

Max 1000 Lumens(XM-L2)


User Manual

1

ACEBEAM™
 An Excellent Manufacturer

About the Acebeam T10

- ⊙ This Acebeam T10 flashlight's versatile modes of output are easily accessible by simply rotating the tail-part then press down the tail cap, please see the below picture.
- ⊙ Generous knurling throughout the surface of the entire light ensures good grip when you most need it.
- ⊙ There are two springs on the head and tail cap for shock damping-This light is ready to be weapon mounted.
- ⊙ Conforms to IPX-8 standard: 1.5 meters.
- ⊙ Removable stainless steel strike bezel for different applications



2

Features

- ⊙ LED: Cree XM-L2 LED with a lifespan of 50,000 hours
- ⊙ Use 1*18650 or 2*CR123A batteries.
- ⊙ Rated operation voltage 3v to 12v
- ⊙ Crenellated SS bezel
- ⊙ Copper base plate for more efficient heat dissipation
- ⊙ Shiny smooth reflector and get perfect beam
- ⊙ Max runtime: 720 hours(0.09 lumens)
- ⊙ Max beam distance: 340 meters
- ⊙ Peak beam intensity: 28900 cd
- ⊙ Impact resistance: 1.2 meters
- ⊙ Waterproof to IPX-8 standard
- ⊙ Size(mm):161.5(length)x42.8(bezel)x25.4(Body dia.)
- ⊙ Weight: 216g(without battery)
- ⊙ Made of durable aircraft grade aluminum
- ⊙ Premium Type III hard-anodized anti-abrasive finish
- ⊙ Toughened ultra-clear glass lens with anti-reflective coating
- ⊙ Battery reverse protection function. And batteries low indication(it will flash when voltage down to 2.7v)

Notice: The above-mentioned parameters (tested with a 3400mAh 18650 battery) are approximate and may vary between flashlights, batteries, and environments.

3

Operation

- ⊙ Mode Switching
 Total five modes: Lock out, Infinite brightness, Firefly, strobe and momentary on .
Lock Out: when you rotate to the Lock Out mode, the tail cap switch can not press down; this can prevent accidental activation of the light.
Infinite brightness mode: Press the tail cap switch and hold on, the light will start to ramp in brightness, choose the brightness you want and then release; the light will memorize the setting. It will retain this setting for future use on this mode. When the light ramps in the brightness. It will blink at 89% output and 8% output by blink twice. When you press and hold on, it will ramp up and switch on again .
Firefly mode: It is a very low 0.09 lumens which is perfect for stealth navigation and for map reading without excessive glare to the user.
Momentary on mode: just hold down the switch for on, release it for off. This mode will always give the max output.
Strobe mode: press and hold for on, release for off.
- ⊙ Battery Replacement
 1. Screw off the tail cap in the indicated direction.
 2. Insert the battery into the body.
 3. When you screw on the tail tap, please align the notch on the tail cap at the slot on the inside of the flashlight body, this way you can screw in the tail cap more easily.

4